MULTIMEDIA
MANUAL

PROTON
INSPIRING CONNECTIONS

ALL-NEW
PROTON X50
INTELLIGENCE THAT AMAZES™

Foreword

Dear users:

Thank you for using our product. Before operating the device, please read this manual carefully to help you understand the proper methods when operating this device for safe use and better entertainment experience!

Please read this manual in detail before you start operating this multimedia unit and navigation device. Perusahaan Otomobil Nasional Sdn. Bhd. reserves the right of final interpretation of this manual.

Important safety considerations:

1. The drivers are prohibited from watching programs and operating the device while driving to avoid traffic violations and accidents.
2. Do not disassemble or repair the device without permission to avoid damaging the device and accidents.
3. Since the device is subject to upgrade, this manual may have discrepancies from the actual operations. Please operate as per the actual conditions.
4. The operating voltage of this device is 9V ~ 16V. The device will restart for self protection when the battery voltage is low.

This vehicle has comply to MCMC requirements. The shown label is the certification mark approved for compliance to standards according to the Communications and Multimedia (Technical Standards) Regulations 2000.



CIDM16000189

All rights reserved. No part of this manual may be reproduced or copied without the written consent of Perusahaan Otomobil Nasional Sdn. Bhd. If you have any questions, kindly contact or visit our website as mentioned to locate the nearest dealer and other available services.

www.proton.com (1-800-888-398)
PROTON EDAR SDN. BHD.
Centre of Excellence Complex
Km33.8 Westbound Shah Alam Expressway
47600 Subang Jaya , Selangor Darul Ehsan , Malaysia.

© 2025 Perusahaan Otomobil Nasional Sdn. Bhd. All Rights Reserved.

Contents

Multimedia System

3 Operation Instructions

3 Notice to Users
4 Safety Information
5 Disclaimers
6 Notes for Navigation
8 Notes Before Using Bluetooth

10 Devices And Operation

10 Steering Wheel Control Buttons
12 Touchscreen Operation

13 Basic Operation

13 System Start-up
14 Screensaver (Lock Screen)
14 Function Manual Screen
15 Homepage (Home Screen)
17 Widget And Shortcut Editing
18 Pull-down Menu
19 Status Bar Menu
20 Apps List Interfaces

21 Phone

22 Dialing
24 Answering and Hanging Up

25 Apple CarPlay*

25 Basic Requirements
25 Connect Apple CarPlay
26 Home Screen
27 Voice Command
29 For More Information

30 Android Auto*

30 Basic Requirements
30 Connect Android Auto
31 Home Screen
32 Voice Command
34 For More Information

35 Multimedia

35 Radio
36 USB and Bluetooth Music
37 Photos and Videos

39 Navigation*

39 Starting the Navigation System
39 Free Navigation Interface
42 Route Navigation Interface
44 Route Planning
48 Navigation Alert
49 Map Report / Feedback
51 Navigation Update

53 A-Store*

53 App Store Introduction
53 Recommended Applications
53 App Display Options

54 Member Center*

54 Account Login
55 Customer Service
56 Diagnostic Tools

57 Weather*

58 Notification Center

59 Theme
59 Switch Wallpaper
60 Switch Screensaver
61 Search Content
61 Display Settings
62 Calendar
62 Calendar View
64 Schedule View
65 Voice Recognition (VR)
65 Common Voice Command
68 VR Setting
69 VR Manual
71 Offline Multimedia Unit*
71 Functions of Multimedia Unit
72 VR Command
74 Air Conditioner (A/C) System
74 A/C Control Buttons
76 Description of A/C Buttons
78 Vehicle Setting
78 Control Centre
78 Vehicle Control
79 Driving
80 Lighting
80 ADAS*
82 Appearance
83 Connectivity
84 My Vehicle
87 360 HD Camera*
87 360 Camera Interface

PROTON Link Mobile App

89 Download The App
89 Register & Link Your Vehicle
89 Discover
89 Recommended & Community
90 Post Your Moments
90 Events
91 Mall
91 Data Add On via PROTON Link
91 Vehicle
91 Remote Control
92 Remote Control Icons Descriptions
93 Air Conditioning Control
94 Trip Log
94 Car Condition
95 Map Services
96 Send Location
97 Service Appointment
98 Test Drive Booking
99 ProCare Services
99 Insurance
100 Profile (My Account)
100 Profile Overview
101 System Settings
101 Message
102 My Schedule
102 Help Center
103 Widget (Vehicle Control)
103 Widget Overview

Operation Instructions

Notice to Users

- Do not use mobile phone while driving. Park the vehicle in a safe place first if you need to use the mobile phone.
- The use of navigation system does not mean that the responsibilities of driver can be replaced. Observe and oblige to traffic rules. Pay attention to the current traffic condition consistently.
- If there is a difference in the traffic regulations and the current traffic condition always take precedence over the navigation system.
- For safety reasons, only operate the navigation system menu before driving or when the vehicle is stationary.
- In case there is only one road or the road is damaged or closed from vehicle entry (e.g. pedestrian street), the navigation system may give a warning. Pay close attention to the warning given.
- The navigation system will not consider route safety when planning a route. Roadblocks, locations of buildings, height and weight limits, traffic and weather conditions or other issues that can affect the safety and driving time will also not be considered in the proposed route. Therefore, it is up to the driver to decide which route is the most suitable route.
- The speed limit stipulated by current road traffic regulations should be more reliable than the system storage most of the time. There is no guarantee that the speed limit shown by the navigation system is the same as that stipulated by the traffic law under any circumstances.
- Do not solely rely on the navigation system to find emergency services (e.g. hospitals, fire-fighting facilities, etc). There is no guarantee that all nearby emergency services in the database are up to date. In this case, driver judgement is required in event of emergency.



It is not recommended to use the navigation system when the engine is turned off.

If this is done, the battery may lose power or drain to flat condition. Always keep the engine running when using the navigation system.

Do not disassemble or modify this device. Otherwise, it may result to accidents, fire and electric shock.

Laws in some provinces and cities prohibit drivers from watching videos during driving. Use the system carefully.◀

Safety Information

This manual provides relevant information of all models. Due to the variety of configurations, the descriptions in this manual may differ from the actual one of your vehicle. The vehicle you actually receive shall prevail.

Warning

Warning indicates that a hazardous situation in which, if not avoided, could result in serious injury or death. The procedures described must be strictly followed. ◀

Caution

It indicates that the steps or requirements stated herein must be observed and followed, or the vehicle may be damaged.◀

Description

It represents a cautionary statement, indicating information that will enable you to better use your vehicle. ◀

Environmental Protection

It indicates that a statement made here is related to environmental protection.◀

Asterisk

The asterisk “*” symbol following a title or name indicates that the configuration or function described is equipped on certain models only. This vehicle may not necessarily have it.

Graphics



Indicate the described object.



Indicate the motion direction of an object.



Indicate the rotation direction of an object.



Indicate that behavior is prohibited or occurrence should be prevented.

Disclaimers

This Manual has been written in compliance with such laws and regulations currently in force. PROTON reserves the right to make such amendments and/or revisions to this Manual as and when required.

This Manual is a copyright owned by PROTON. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission from PROTON.

All the data contained in the manual are the latest data at the time this manual is published.

The pictures in this manual are for reference purpose only. PROTON reserves the right of final interpretation of this manual.

When transferring the vehicle, please remember to pass the information of this manual on to the new user as this manual is an integral part of the vehicle. ◀

This multimedia manual is available at Proton official website, together with the owner's manuals for this model. Refer to QR code provided at the back cover of this manual.◀

PROTON has the right not to provide the service for you in the following cases:

- Violation of local laws and regulations.
- Provision of false registration information.
- Unauthorized use of services.
- Application of products and services for any illegal purposes.
- Behaviors which harm to the interests of other users.
- Abuse of user rights.
- Behaviors violating social customs and social morality.
- Acts inciting national hatred and discrimination, as well as undermining national unity.
- Acts spreading obscenity, pornography, gambling, violence, murder, terrorism or abetting crime.
- Acts harming national security, divulging state secrets, subverting state power and undermining national unity.

After correction, PROTON has the right to decide whether to resume the service on the case to case basis.

Notes for Navigation

Description of Terminology

- ***Point of Interest (POI):*** Feature point marked on the map that provides the name, attributes and location information, such as petrol stations, hotels, schools, etc.
- ***Positioning:*** A function in the system for displaying the inquired points of interest in the center of the navigation screen and prompting the name and location.
- ***Route planning:*** A function in the system for selecting a planning method according to the starting point, the passing point and the bypassing point, and calculating a path that meets the needs of users.
- ***Navigation:*** A function in system for planning route based on geographic information software and guiding the user with voice assistance throughout the travel. Navigation in geographic information software includes the simulated navigation and actual navigation. It refers to real navigation unless otherwise specified.
- ***Move map mode:*** Users can move the map by clicking or dragging the map according to their habits. Other terms will be described in detail in the text, so no repetition is made here.

Navigation System

This device is equipped with a state-of-the-art navigation system that assists driver to a desired location with the objective of delivering a smooth comfort driving experience.


Please read the following warnings carefully before start using the navigation system. For your driving safety, strictly observe the “Warning” operation. PROTON will not be responsible for any inconvenience or accident caused by negligence of the stated warnings. ◀

Navigation System Disclaimer


- ***Map disclaimer:*** In certain situations, due to on-going constructions, rapid development of rural highway, continuous changes in traffic control information and traffic facilities in urban streets, the information displayed by the system may not completely consistent with the actual information. Thus, the driver must pay serious attention to the actual traffic conditions and avoid violating the traffic rules. The navigation map will be released to the public in a timely manner.

  Due to changes in traffic regulations or temporary road control, the route planned by the navigation map may not conform to the actual traffic control situation. Please drive according to the actual traffic control or traffic rules.

- ***Navigation disclaimer:*** As the actual road conditions sometimes change, the driving routes planned by the navigation map are only recommendations and may or not be used as factually accurate reference. For example, the route chosen by the driver in his/her familiar area may be more effective than the route planned by the navigation map.
- ***Satellite signal reception disclaimer:*** In general, the navigation map can calculate your exact location after only 3 or 4 satellite signals being received. However, due to weather or under the influence of tall buildings in the city, sometimes the reception of signals will be affected, as shown in the following figure:



- ***Error disclaimer:*** Under normal conditions of satellite signal reception, the standard satellite positioning system error is in the range of 5 to 10 meters. There are conditions when the position of the road may not be exactly consistent with the position of the vehicle shown on the map. The vehicle may be shown on the opposite parallel road close to the actual driving road.The following illustrations show the conditions which may affect the normal reception of satellite signals and cause errors.



GPS Status Indicator



GPS status indicator: Red and yellow colours indicate an abnormal GPS status, while green colour indicates normal GPS status.

Failure to receive satellite signals:

- Check whether the icon of reception status in GPS information display is normal.
- During start-up, the satellite antenna needs to receive satellite signals and update internal information. If the reception status icon indicates that there is no signal, wait for a moment to allow the signal to enter normal operation.
- Check whether the vehicle is located in an area that can possibly interfere the satellite signal reception such as “under a bridge”, “in a tunnel” and “near tall buildings”. After the vehicle exits such areas, the signal will be restored.

Safe Navigation

Do not operate the navigation function while driving to avoid distraction and cause safety problems. The navigation setup should be done in advance or operated by passengers.

Safe navigation is the top priority to ensure the personal safety of drivers, passengers and others.

Use Instructions

Before using the navigation system, please take note with the following information:

- The accurate guidance and positioning of the navigation system is closely linked to GPS signals, and the navigation system will automatically search for GPS signals.
- It may take 2 to 15 minutes for initial positioning and 1 to 3 minutes for repositioning.
- Being in complex terrain such as in the basement and between tall buildings, there may be no GPS signal.
- In the event of the absence of GPS signals, please drive the vehicle according to the actual road conditions.

Notes Before Using Bluetooth

Description of The Wireless Bluetooth Technology

- Wireless Bluetooth technology is based on short-range wireless network technology, which enables different devices to connect in short range at a frequency of 2402 MHz ~ 2480 MHz.
- It supports various electronic devices such as computer, external devices, Bluetooth phones, and PDAs. With regard to application in vehicles, wireless Bluetooth technology can achieve high-speed transmission without using a cable.
- Bluetooth phone means that the user can conveniently make a phone call via Bluetooth connection.
- Some phones may not be supported by the function of Bluetooth phone.

Notices for Safe Driving

- Bluetooth phone can improve the safety of driving. After the phone is connected via Bluetooth function to the system unit, the user can conveniently make a call, answer a call and manage the contact.
- Please read this user manual carefully before using the Bluetooth phone.
- It is prohibited to operate the Bluetooth device frequently while driving. This may cause negligent driving that can result in an accident.
- Avoid looking at the screen for long periods while driving. This is dangerous and may cause an accident.


Reminder for Pairing Bluetooth Phone


- Before pairing your phone to the multimedia system unit, check to see if your phone is equipped with a Bluetooth function.
- If you do not want your vehicle to be automatically Bluetooth connected to your phone, stop the vehicle and deactivate the Bluetooth function in the phone.
- Some Bluetooth functions may not be activated properly due to the software version of the phone. Disconnect the current Bluetooth connection and update your phone with the latest software version provided by the phone manufacturer. Once completed, pair your phone with the system unit again.

Devices And Operation

Steering Wheel Control Buttons

The steering wheel control buttons for multimedia unit is located on the left and right side (***Multi-control Function Buttons***) of the steering wheel. The functions mentioned below for multi-control function buttons on the right side of steering wheel are during the meter instrument is closed via Mode switch button (the button is currently controlling the multimedia unit).





No.	Buttons	Short Press	Long Press
1.	Home button	Press this button briefly to return to the previous menu or interface.	-
2.	Selection and Confirmation button (volume up/ down)	Move this button up or down to adjust (increase or decrease the audio source volume from the multimedia unit. Press this button to hide regular alert messages or pause the playback of audio source from the multimedia unit.	Move this button up or down to continuously increase or decrease the audio source volume from multimedia unit.
3.	Mute button	Short press to mute or unmute the audio source.	-

No.	Buttons	Short Press	Long Press
4	Right Selection button (Next)	To seek or switch to the : • Radio: next station • Music: next song • Video: next video	To seek next station and to fast forward the song or video.
5	Mode Switch button	To switch the control of the multi-control function buttons between the meter instrument and the multimedia unit (open or close the main menu of meter instrument).	
6	MODE button	To change between audio sources.	
7	Left Selection button (Previous)	To seek or switch to the: • Radio: previous station • Music: previous song • Video: previous video	To previous station and to rewind the song or video.
8	Call button (phone)	Press this button briefly to : • Answer the Bluetooth phone. • Hang up during a call or cancel making a call. • Enter phone interface when in idle.	Press and hold this button to : • Hang up during a call or cancel making a call. • Dial the last call when in idle.
9	Voice button (VR, Voice Recognition)	When VR is not activated, press this button to enter the VR mode function. When VR is activated, press this button to exit the VR mode function.	

Touchscreen Operation

No.	Finger Gestures	Action
1		***Tap :*** Activate an application, activate button functions and locate the progress bar
2		***Horizontal scroll or swipe :*** Move or drag a page to the left or right
3		***Double tap with one finger :*** to enter the interface or apps
4		***Squeeze inwards :*** squeeze using two fingers inwards to zoom in
5		***Squeeze outwards :*** squeeze using two fingers outwards to zoom out


Basic Operation


System Start-up

When the power of the system is OFF, turn the ignition to ACC or ON position and the multimedia system will start automatically. A start-up animation and a warning message will pop up on the multimedia screen.

Screensaver (Lock Screen)

- Tap the ***Screensaver*** icon to enter the Screensaver or lock screen interface. See the Pull-down menu section.
- Tap on any area of the interface to unlock (exit) the screensaver interface.







Function Tutorial Screen

Each time open into an apps or a function inside the multimedia unit, a pop-up function manual screen will appear to provide information on the buttons and step to use the apps or function.


Refer to figure below for example. Select the ***Do not show again*** and the pop-up display will not appear again.





Homepage (Home Screen)

The home screen is designed to give you the experience similar to that of Android devices. The homepage mainly displays time and widgets such weather, calendar and navigation. The homepage featuring two desktop modes.



1. Status Bar : Located at the top of screen. Quick control to log in account, Wi-Fi connection, Bluetooth connection, VR button


2. Widgets : Scroll to left / right to see the available widgets. These widgets can be changed based on user preferences from the available applications in multimedia unit.

3. Dock Bar : Located at the lowest row of the screen. The 3 left bottom shortcuts icons are editable. The picture above is showing shortcuts to bluetooth call, navigation and audio (multimedia).

Wallpaper Desktop Mode

The default setting for homepage is night mode. See Display at Setting section to change the background mode between day mode and night mode.


The day mode will provide brighter background as following:



Navigation Desktop Mode


The map is now integrated as the desktop background, offering a seamless and immersive navigation experience right from the home screen.


Switch between the Wallpaper desktop mode to Navigation desktop mode via pull-down menu and vice versa.



Widget And Shortcut Editing

- Long press widget and shortcut to add, edit and remove the widgets and shortcuts based on user preference.
- Long press on homepage to enter edit mode. Tap **“ + ”** to add widgets or layouts, and **“ - ”** to remove existing ones.
- This function support the tap-and-drag movement in editing mode for easy arrangement.






Pull-down Menu

Swipe down from the top of the multimedia screen display to show the pull-down menu. All functions can be switched on/off quickly including quick configure to Wi-Fi, Bluetooth, Hotspot, Screensaver, other vehicle settings, screen brightness and volume adjustment.


User can seamlessly switch between Wallpaper Desktop mode for a personalized visual experience, or Navigation Desktop mode for focused driving assistance.



Long press any shortcut icons to add/delete the shortcuts to/from the pull-down menu.

Tap “ **+** ” to add a shortcut function.


Tap “ **X** ” to delete a shortcut function.





User can also configure the shortcuts in pull-down menu. The “Confirm” button on top right corner will let user confirm the current configuration.

Status Bar Menu

Tap any icon on status bar (on top of multimedia screen display) to open the status bar menu where user can quickly access to account login, Wi-Fi, and Bluetooth settings.








Apps List Interfaces


Tap ***App List Interface***  a icon or swipe the screen left/right to enter the app list interfaces that provides various apps such as Settings, Phone, Gallery, etc. to meet the needs of the driver and passengers. At the same time, the system will be gradually updated and improved, and more user-friendly applications will be introduced




App list interface includes Media, Image and Video Entertainment, Online Navigation, VR Voice, Weather and more Apps that meet most driving scenarios. In the app list interface, users can now edit, delete, and re-order the sequence of apps.

Apps List Folder Creation

New feature in the apps list interface allows users to create folders which will make it easy for user to customize and streamline the app experience. To enter edit mode (apps folder creation), long-press any apps icon and drag it to rearrange its position.




Hold and drag one apps icon onto another to create folder. Once a folder is created, tap on the folder to edit its name. Clicking or tap outside the folder area will save the new name automatically.



To manage apps within folders, hold and drag any apps icon to move it back to the main App list interface from within the folder. Sample of complete folder as below:

Phone

Tap to open **Phone app** at homepage or from app list interface. Before making a call via multimedia unit, it is advised to connect the phone via bluetooth pairing.




Enter the Bluetooth interface at vehicle setting to turn on/off the Bluetooth function and customize Bluetooth information (see Setting section for details). Search for available devices to be paired to the multimedia unit. The selected mobile device will receive pairing notification requesting to confirm the pairing process.

Dialing

Various methods of making a call using the multimedia unit are as follows. Tap the name or dial and then tap the phone icon to start dialing:


1. Call via keypad.



2. Call via contacts.



3. Call via recent calls.



4. Call via VR Voice.

   After awakening the VR Voice, calls can be made via the voice command. Refer to Voice Recognition (VR) section for setting and voice commands.


Answering and Hanging Up

Answering and hanging up calls can be done via steering wheel control buttons (the multi-function control buttons at the steering wheel).


While the Bluetooth phone function is active:

- Press Phone button on the steering wheel to answer or hang up the call.
- During the call, adjust the call volume by pressing up/down the volume button.


Tap on to the name or contact number to make bluetooth phone call. You can answer or hang up via multimedia unit on bluetooth phone call interface as below.



Call Status Display: Shows real-time call information, including active calls and any calls placed on hold, for clear and easy call management.



Apple CarPlay*




About Apple CarPlay

CarPlay brings the most useful apps from smartphone to vehicle screen of Infotainment Head Unit (IHU) or also known as multimedia unit, optimized for easy glancing and control while driving. With CarPlay you can get turn-by-turn directions, make phone calls, text messages, listen to music and more all from your vehicle screen of IHU.

Basic Requirements

- An iPhone with iOS 5.0 or higher, an active data plan, Wi-Fi support, Bluetooth support and update your phone to the latest iOS version.
- A vehicle Infotainment Head Unit (IHU) that is compatible Apple CarPlay.
- An Apple Lightning to USB cable or a high-quality certified USB cable.
- Siri must be enabled to use Apple CarPlay.

Connect Apple CarPlay | Wireless connection




- Keep your iPhone's Siri, Bluetooth, Wi-Fi and Location Services turned ON.
- Ensure your vehicle is in Park (P) and the parking brake is engaged before starting the setup to prevent distractions.
- Make sure IHU is powered ON. Apple CarPlay requires the system to be active. ◀

1. For the first-time user, pair your phone with vehicle IHU via Bluetooth.
2. Once your phone is paired with vehicle IHU via Bluetooth, Apple CarPlay should start a few seconds and follow the on-screen prompts to enable Apple CarPlay (you may need to tap Apple CarPlay icon on IHU screen and tap “Allow” on the pop-up notification displayed on your iPhone).

Connect Apple CarPlay | with USB Cable








- Keep your iPhone’s Siri turn ON.
- Ensure your vehicle is in Park (P) and the parking brake is engaged before starting the setup to prevent distractions.
- Make sure IHU is powered ON. Apple CarPlay requires the system to be active. ◀

1. Plug the USB cable to your vehicle’s USB Port and plug in the other end into your iPhone.
2. Follow on-screen prompts to enable Apple CarPlay. (You may need to tap Apple CarPlay icon on IHU screen and tap “Allow” on the pop-up notification displayed on your iPhone).

Apple CarPlay | Home Screen




No	Description
1	Status Area: Signal strength, battery status and time.
2	Recent apps: Most recently used apps
3	App launcher: To access list of all available Apple CarPlay apps, tap on the app launcher icon.
4	Dashboard: Maps navigation and recent places, Call and messages, Music and audio, etc.

Apple CarPlay | Voice Command

- Voice command used in Apple CarPlay is “Siri”.
- Siri can be used to access many of your phone’s functions while driving to enter a destination, send messages and make calls without having to pick up your phone.

Activating “Siri”

1. **Saying Commands**
   - Say “Hey Siri”.
   - The Siri will pop-up on your Apple CarPlay screen, and you will be prompted to say a command.
   - Speak your command clearly.




For more information on Siri functionality visit: https://www.apple.com/ios/siri/ ◀

2. **Steering-Wheel Controls**
   - Press and hold the “Voice Recognition” button on the steering wheel to activate Siri.




Not all third-party apps support voice recognition through Siri. ◀

Apple CarPlay | Map and Navigation




You can navigate using “Apple Maps” or compatible third-party apps such as “Waze”. Provides you voice-guided navigation, estimate arrival times, live traffic information and lane guidance.

Apple CarPlay | Phone Calls




You can make and receive calls with Apple CarPlay. You’ll hear your conversation through your vehicle speakers.

Apple CarPlay | Messages



You can tell Siri to send a text message by voice, read your received text messages and messages from third-party apps (e.g. Whatsapp)

Apple CarPlay | Music and Audio



You can access all your favourite music, podcasts, audiobooks and more are just a command away.


For More Information

- Check your vehicle Owner's Manual for additional instructions.
- Or visit the Apple CarPlay website at https://www.apple.com/ios/carplay/
- You can access all your favourite music, podcasts, audiobooks and more are just a command away.

Notice

- Apple CarPlay is a service provided by Apple, Inc. bounded by their terms and conditions. When using Apple CarPlay, information will be sent from your vehicle (including its position) to the connected iPhone. You will be solely responsible for anyone using the service on your vehicle.
- The Infotainment System (Multimedia unit) only acts as an intermediary interface for accessing iPhone functions.
- Features and behaviors are dependent on the iPhone device, the iOS version, the app, and the media file played.
- While in Apple CarPlay, the Accept Call Button on your steering wheel can only be used to answer incoming calls.
- When using Apple CarPlay, please avoid distraction and use Apple CarPlay responsibly. Stay fully aware of driving conditions and always obey applicable laws.

Android Auto*




About Android Auto

Android Auto brings the most useful apps from smartphone to vehicle screen of Infotainment Head Unit (IHU) or known as multimedia unit, optimized for easy glancing and control while driving. You will be able to control things like navigation, maps, calls, text messages and music all from your vehicle screen of IHU.

Basic Requirements

- An Android phone with Android 6.0 or higher, an active data plan, Wi-Fi support, Bluetooth support, Android Auto app and update your phone to the latest Android version.
- A vehicle Infotainment Head Unit (IHU) that is compatible Android Auto.
- A high-quality USB cable which certified USB cable for the in-vehicle connection.


Connect Android Auto | Wireless



- Keep your phone's Bluetooth, Wi-Fi and Location Services turned ON.
- Ensure your vehicle is in Park (P) and the parking brake is engaged before starting the setup to prevent distractions.
- Make sure IHU is powered ON. Android Auto™ requires the system to be active. ◀

1. For the first-time user, pair your phone with vehicle IHU via Bluetooth.
2. Once your phone is paired with vehicle IHU via Bluetooth, Android Auto should start a few seconds and follow the on-screen prompts to enable Android Auto (you may need to tap Android Auto icon on IHU screen).


Connect Android Auto | with USB Cable



- Ensure your vehicle is in Park (P) and the parking brake is engaged before starting the setup to prevent distractions.
- Make sure IHU is powered ON. Android Auto™ requires the system to be active. ◀

1. Plug USB cable in your vehicle's USB port and then plug the other end of the cable into your phone.
2. Follow on-screen prompts to enable Android Auto. (You may need to tap Android Auto icon on IHU screen).

Android Auto | Home Screen



No	Description
1	Status Area: Signal strength, battery status and time.
2	Recent apps: Most recently used apps


No	Description
3	Microphone: To activate Google Assistant, tap the icon, say “Hey Google” or press and hold Voice Command button on the steering wheel.
4	App launcher: To access list of available Android Auto™ apps, tap on the app launcher icon.
5	Dashboard: Maps navigation and recent places, Call and messages, Music and audio.

Android Auto | Voice Command

- Voice command used in Android Auto is “Google Assistant”.
- Google Assistant can be used to access many of your phone’s functions while driving to enter a destination, send messages and make calls without having to pick up your phone.

Activating “Google Assistant”

1. **Saying Commands**
   - Say “Hey Google”.
   - The Google Assistant bar will pop-up on your Android Auto screen, and you will be prompted to say a command.
   - Speak your command clearly.




For more information on functionality of the Google Assistant, visit: https://assistant.google.com/platforms/cars/ ◀

2. **Steering-Wheel Controls**
   - Press and hold the “Voice Recognition” button on the steering wheel to activate Google Assistant.




Not all third-party apps support voice recognition through Google Assistant. ◀

Android Auto | Map and Navigation




You can navigate using “Google Maps” or compatible third-party apps such as “Waze”. Provides you voice-guided navigation, estimate arrival times, live traffic information and lane guidance.

Android Auto | Phone Calls




You can make and receive calls with Android Auto. You’ll hear your conversation through your vehicle speakers.

Android Auto | Messages



You can tell Google to send a text message by voice, read your received text messages and messages from third-party apps (e.g. Whatsapp)

Android Auto | Music and Audio



You can access audio entertainment through Google Play Music or compatible third-party music and media apps. (e.g. Spotify, YouTube Music)

For More Information

- Check your vehicle Owner's Manual for additional instructions.
- Or, visit the Android Auto Help Center at https://support.google.com/androidauto/
- For full list of apps compatible with Android Auto, visit https://www.androidauto/auto/

Notice


- Android Auto is a service provided by Google LLC, bound by their terms and conditions. When using Android Auto, information will be sent from your vehicle (including its position) to the connected Android device. You will be solely responsible for anyone using the service on your vehicle.
- Google, Android, Google Play, Android Auto and other marks are trademarks of Google LLC.
- The Infotainment System only acts as an intermediary interface for accessing Android device functions.
- Features and behaviors are dependent on the Android device, the OS version, the app, and the media file played.
- When using Android Auto, please avoid distraction and use Android Auto responsibly. Stay fully aware of driving conditions and always obey applicable laws.

Multimedia

Tap to open **Media app** at homepage or from app list interface to enter the media interface and select between Radio, USB or BT (bluetooth) as source of multimedia entertainment.

Radio

In the media interface, tap ***Radio*** to enter the radio interface to seek and play the preferred radio station.




1. Switch between FM and AM radio station.
2. Search or scan radio stations.
3. Previous radio station : automatically search for the last available radio station.
4. Pause / play radio.
5. Next radio station: automatically search for the nearest frequency radio station.
6. Rebroadcast : 5 seconds rebroadcasting
   - From the current frequency, seek the next station in the direction of +.
   - Play 5 seconds.
   - Continue to seek the direction of +.
   - Repeat the above steps until the starting scanned frequency is returned.
7. Adding radio stations to favorites.
8. Favorite list of radio stations.
9. Display playing radio station frequency and name.

USB and Bluetooth Music


The multimedia unit supports the following audio files formats: MP3, WMA, AAC, WAV, OGG, FLAC. Audio files stored in USB flash drives can be read and played.

In the media interface, tap ***USB*** to enter the USB interface to play audio file in the USB flash drive. Make sure to connect the USB flash drive to USB port first.



Audio files from a Bluetooth device can be played via Bluetooth connection with the multimedia unit.

In the media interface, tap ***Bluetooth*** to enter the bluetooth interface to play audio file in the connected bluetooth media device.



Make sure to pair and connect the bluetooth media device first to play the available music.


Photos and Videos

Tap **Gallery app** or **Video app** at homepage or from the app list interface to browse available photos and videos from local drive and USB flash drive.


Photo

The multimedia system supports the following image file formats: JPG, JEPG, PNG, GIF (static), BMP and GIF (only for the first image in the truncated GIF image sequence).

Photos stored in USB flash drives can also be viewed and displayed from the Photo app.



User can also choose to upload photos into local vehicle storage by clicking the top left button and scanning QR code. The photos and images files can be transferred between USB flash disk to the local disk of the multimedia unit.



Easily transfer images from phone to the multimedia unit local disk for better viewing and organization. Now, you can transfer and store up to 9 photos at once, enhancing your display options.

Video

The multimedia unit supports video files in the following formats: 3GP, FLV, MKV, MP4, AVI, MOV.

The multimedia unit also supports video files in the following video encoding formats: MPEG, MPEG2, MPEG4, AVC, XVID, MJPEG.



Videos stored in USB flash drives can be viewed and displayed on the multimedia unit.

Please be aware that the multimedia unit will not allow videos to be played during driving. Hence, a reminder will be displayed if it was found that the vehicle is currently in drive mode.

Navigation

Starting the Navigation System


After starting up, tap ***Navigation widget*** or say the voice command ***"Open Navigation"*** to run the navigation system.

There are two modes in the navigation system:

- ***Free navigation mode:*** No destination is set after you enter the navigation system.
- ***Route navigation mode:*** After you enter the navigation system, set the destination first, and then the system starts the route calculation and navigation according to the destination you set.

Free Navigation Interface

The following describes the navigation screens and related functions :




1. Search destination: Click to search for the destination you want to go to.
2. Settings: Click to open Settings interface and make adjustments to navigation settings.


Search Destination

If the vehicle is connected to the network, the online map data can be used when searching a destination. Otherwise, the search result is based on the local map data. Otherwise, the search result is based on offline map data.Therefore, the results of online and offline search may be slightly different.

Tap ***Search Destination***  icon to enter the ***Search Main Interface***, and complete the manual search as below:



Then select ‘More’ to reveal a categories list, such as restaurant, parking lot, hotel and more. This feature makes it easy to explore a wide range of places tailored to your interests or needs.




Select the destination from the searched results to start navigation.

Location Overview


Once a location is selected, you can save it, perform a nearby search, or directly view its detailed information.

Select Direction to set the navigation route and enter the Route Navigation Interface.




Maps Settings

In the map settings, you can customize various options such as vehicle logo style, map color mode, traffic view, auto zoom, and more.




Route Navigation Interface

Set destination to enter route navigation interface. On the route navigation interface, tap anywhere on the map to access route navigation options. After selecting a destination, follow the route with turn-by-turn guidance displayed on the screen.




1. **Overview** : Tap this icon to enter route overview mode. Click ***Overview*** to display all routes on the map.
2. **Exit** : Tap this icon to exit current on-going navigation and re-route.
3. **" ... "** : Tap this icon. The operation icons will be displayed as follows:




Search Along the Route

Tap to search for nearby amenities such as parking lots and coffee shops; or to set the amenities as stop point along the route.



Route Edit

Tap to edit current route, such as adding, deleting and changing route; or to adjust the sequence of routes.




Reroute

A quick route recalculation butto, allowing users to recalculate the route using their current location as the starting point, with the destination remaining unchanged

Turn by Turn (TBT)

Tap to view all turn list information along the route.




Route Planning

If current destination has already been set, user can add pathway by using relevant keywords and pinning on the map to re-plan the route.

Keyword Search

Tap this to perform search by entering keywords such as “hotel” and the search results will be displayed.


Then, select an address to view the search location in the map.



View Search Location


View location on map able to check its details, save it to favorites, set it as a stop or destination, explore nearby places, or return to your current location.

Select an address to view search location in the map as below.



Planning and Selecting Routes


Navigation routes to destination will be provided on this interface with comparison information including expected arrival time, total distance, and numbers of traffic light.




Favourite Location

You can save your desired destination here. When you need to navigate to a destination listed in favourites, just select the destination from the favourite list.


Saved locations can be found under Favorites after logging into your Member Center account.






Customize Common Categories


Tap this to view all categories and customize common categories via the Edit icon.






Navigation Alert


Map view will auto-zoom at turn junctions for better guidance.



When approaching destination, navigation system will recommend nearby parking lot.




You can view parking lot on the map and click the “ **P** ” icon to view the detail information.




Map Report / Feedback

In the settings interface, you can use ***Map issue*** under Map report pop up as shown below if you would like to report about location on the map.



Report a New Place

If you find a new place but it does not exist in the map data, you can use ***New place*** in Map report interface above to report this new place.




Tap on the ***Map report*** → ***Map issue*** → ***New place*** to report a missing place by submitting its details to update the map data.

Input is mandatory for items marked with " * ". Tap Submit to send the report.

Report a Location Error

If a location is found to be inconsistent with the map data, the error can be reported. Use ***Place wrongs*** in Map report interface above to report the error.




Tap on the Map report – Map issue – Place wrong if a location is found to be inconsistent with the map data, the error can be reported. Use Place wrongs in Map report interface above to report the error.

Other Traffic Report

Enable users to report road closures through the navigation app, and once confirmed, the system will automatically adjust routes to bypass closed roads for other users.

The system is leveraging the reported traffic incident data (such as roadwork and road closures) to improve route calculation and navigation.



Navigation Update

Please visit an authorised PROTON service outlet and ask the staff to update your offline map data.

Online Map Data Update

If the navigation system detected a new map data need to be updated to the system, an online full map data update will be triggered when launching the navigation.

Map update steps:

Step 1 : Start the navigation. The navigation will check whether the current map version need to be updated. If update is required, the above page will pop up to guide the user to update the map database online.

Step 2 : Tap on “Online map update” as above and a page confirming whether to download or not will pop up.

Step 3 : After tapping “Confirm”, the following screen will be displayed. The whole map data for navigation will be downloaded from the Internet. Under normal network transmission speed, the download can be successful within ten minutes.

Step 4 : If you tap the “Download” button and the download progress screen is not displayed, instead a message “Network Connection Failed” is displayed, please confirm the following:

- Check the network connection of the vehicle.
- If the network connection is good, tap “Retry” button to download again.
- If the download is still unsuccessful after several attempts, tap “Exit” and restart navigation app to reinitiate the download.
- If the network connection is poor, try again several times.
- If the above attempts still fail, please contact your authorised PROTON service outlet.

Step 5 : If the message Map Download Failed is displayed during the download process, check the following items:

- Check the network connection of the vehicle.
- If the network connection is good, tap Retry button to download again.
- If the network connection is poor, try again several times.
- If the above attempts still fail, please contact your authorised PROTON service outlet.

Step 6 : Once the progress reaches 100%, the download has completed. The system will start local update and install, as shown below.

When the network transmission speed is normal, the update and installation can be successful within two minutes.

If the network signal is poor and the transmission speed is slow, the time taken will be longer depending on the network signal strength and transmission speed.

Step 7 : If “Map Update failed. Please contact the Dealer” is displayed during the update process, please confirm the following:

- First try to exit the navigation app, restart the navigation app and download the map data again.
- If multiple attempts fail, restore factory settings and download again.
- If the above attempts still fail, please contact your authorised PROTON service outlet.

Step 8 : After the installation has completed, the following screen will be displayed, indicating that the map data update and installation of the entire map is completed.

Tap “Confirm” to exit the navigation and restart the navigation again.


A-Store*

A-Store (application store) allows users to download preferred applications to be installed on the multimedia unit (IHU).

The A-Store provides a variety of software such as basic apps, music, weather, themes, and other relevant software and services provided by various partners for the users to download.


Recommended Applications

Explore a curated list of recommended apps. Users can view and download available applications from the **Market**.



App Display Options


Downloaded apps can be viewed under **My APP**. This section shows the status of each app, indicating whether it is up to date or requires an update.



Member Center*

The Member Center offers easy access to vehicle information and user account management. It features a variety of services that create a seamless driving experience.


The user can access the Member Center using a guest account or by logging in with phone number and password.




Account Login

User can log in to member account by scanning the QR code or entering the phone number and password in the Member Center interface.

Get easy access to account login QR code by tapping the icon at status bar menu.






After logging in, user can view their Nickname, Profile Picture, and check internet usage and purchased data.

Customer Service


For assistance, contact Customer Service at the Call Centre: 1800-888-398.




Diagnostic Tools

Select **Tools** to access the Diagnostic tools from Member Centre.

Use the Diagnostic Tools to test multimedia unit (IHU) information, SIM card and its Networking Device details including the GPS signal, Network status, Network connectivity test performnce, and exporting the log files.






Weather*

Tap Weather app or weather widget at the homepage to enter weather interface.

The following will be displayed when using the weather app. By default, the weather is displayed for the city in which the vehicle is currently located. Other locations and cities can be added in the app settings. The background of weather will change according to the corresponding state.




There are Malay version of the weather app, provided the language setting has been changed to Bahasa Malaysia.



Add new city


User can add cities to get multiple cities weather information.

Type on search tab to find other locations and cities to be added in the weather app settings. Suggestion will be listed as shown in figure below.



Notification Center

User will be able to read notifications and messages which can be viewed later or instantaneously by tapping the top right corner of the multimedia unit screen.



The Notification Center can be swiped down to be displayed or swiped up to hide. There is also a button to clear all messages.

Theme


Tap **Theme app** in the App List to enter the interfaces for wallpaper, screensaver, and my download (personalized interface).

User can select and change wallpapers in the Theme interface. User can also choose screensaver clocks, which supports displaying digital and analog clock.


Switch Wallpaper

Tap **Theme app** → **Wallpaper** to open wallpaper interface.

Choose from the selected wallpapers and switch more personalized options between them according on user preferences.



Click on the preferred wallpaper to select and see its details. Click apply and confirm the selection to switch the wallpaper.




Once confirmed, the apply button will dim and the word will change to applied, indicating that the selection has been set as current home page background.


Switch Screensaver

Tap **Theme app** → **Screensaver** to open screensaver interface.

Switch to preferred screen saver and set screensaver for the screen lock page.




Click on the preferred screensaver to select and see its details. Click apply and confirm the selection to switch the screensaver. System will download and apply the selected screensaver clock.



Once confirmed, the apply button will dim and the word will change to applied, indicating that the selection has been set as current pattern when locking the screen.

Search Content

Tap **Theme app** → **Search** to key in search keyword for available multimedia unit's wallpaper and screensaver options. Download or purchase to install new preferred selection, and it will be avaialable to be used at **My Download** section.



Display Settings

Tap **Theme app** → **Display Settings** to enable the Auto Change Wallpaper feature which will automatically download and apply new wallpapers during event (desktop wallpaper mode), enhancing your experience without manual intervention. When the event is over, it will reverts to your original wallpaper.



Calendar


Tap Calendar app in the App List to enter the calendar interface and view the selected date calendar as well as personalized schedule.

Calendar View


Calendar can be viewed by year, month, and date as below figure. Holiday information is also available. Tap on an agenda (***Event***) to view full details.

Specific date can be selected via ***Schedule Date***.


- Calendar view by Year




- Calendar view by Month




-



- Calendar view by date (Day)






Schedule View

Schedule created in the multimedia unit can be displayed with dates and annotations.

Check on mobile app to schedules with dates and notes

Select date and click on Event to view the schedule details.



Voice Recognition (VR)


Voice recognition (VR) application, is an application similar to a voice assistant. It helps you to reduce your dependency on hands and eyes for in-car device operation to improve your driving focus and safety.

The voice command function in VR app is designed to offer a smart, seamless, and humanized experience for users interacting with the multimedia unit. Voice command function can help you better when using various applications of the system.



VR Setting

Tap **Vehicle Setting** → **VR**, to customize voice recognition settings such as changing the VR Voice (selection between Atlas for man's voice or Aethra for woman's voice), enable/disable the auto wake up function (Hi Proton), setting user's name and accessing the VR manual.




VR Manual

The VR manual provides user with more information about voice supported functions, features and characteristics.


VR Help

Tap **Vehicle Setting** → **VR** → **VR Manual**, to access the VR Help that introduces the VR functions and voice commands examples that can be used to communicate with multimedia unit.



At VR Help interface, voice commands are divided into group of folders such as Navigation, Music, Radio, Phone, System Control, Windows Control, Air Control, Inquiry and Quick Command.

Select and tap the folder that will provide VR special features and potential uses of respective group





VR Help (Bantuan VR)

VR Help (*Bantuan VR*) can also be set between English or Malay language.

Tap **Vehicle Setting** → **Appearance** → **Language**, and select Bahasa Melayu to change the language. Select Confirm to continue with Malay language and now VR Help will be known as **Bantuan VR**.

Example of **Bantuan VR** *interface at Multimedia unit display:*






Search Commands

At VR Help interface, type keyword at search commands on upper right side of the interface. System will search the potential voice commands that is related to the keyword.

Common Voice Command

Wake Up


There are three ways to wake up (activate) the VR app.

- Use **voice command** to multimedia unit : **Hi Proton.**
- Press the **voice button** on the steering wheel to wake up the VR app.
- On homepage or any interfaces, tap the **VR icon** at centre upper corner of the screen (at the status bar). 

Exit

There are three ways to exit (close) the VR app.

- Use **voice command** to multimedia unit : **Exit / Cancel / Bye.**
- Press the **voice button** on the steering wheel once again to exit the VR app.
- On VR interaction interface, tap **X icon** at upper right of the interface.



Voice Control Command

Voice commands and their corresponding functions are not limited to the examples as listed in the table of common voice command below. The multimedia unit can interpret other common phrases with clear instructions.

Refer to VR Manual at multimedia unit for more voice command examples either in English language (VR Help) or in Malay language (Bantuan VR).

Group (*Kumpulan*)	Example of Voice Command (*Contoh Arahan Suara*)
Navigation *Navigasi*	Open navigation / open map *Buka navigasi / buka peta*
	Start navigation to 'KLCC' *Mulakan navigasi ke 'KLCC'*
	Stop navigation *Hentikan navigasi*
	Show my location *Tunjukkan lokasi saya*
	Set office address *Tetap alamat pejabat*
	Zoom in / zoom out *Zum dekat / zum jauh*
Music *Muzik*	Play 'Lonely' (song title) *Mainkan 'Lonely' (tajuk lagu)*
	Save this song *Simpan lagu ini*
	Who is the singer? *Siapa penyanyi lagu ini?*
	Volume up *Kuatkan bunyi / Tambah kelantangan*
	Previous / next song *Tukar lagu sebelum / seterusnya*
	What song? *Lagu apa ini?*
Radio *Radio*	Listen to FM 92.9 (use radio frequency) *Dengar FM 92.9 (guna frekuensi radio)*
	Tune to 'Hot FM' (use radio station name) *Tukar ke 'Hot FM' (guna nama stesen radio)*
	Add to favorite list *Simpan ke stesen kegemaran*
	Next station Stesen seterusnya

Group (*Kumpulan*)	Example of Voice Command (*Contoh Arahan Suara*)
Phone *Telefon*	Make a call *Buat panggilan telefon*
	Dial 'Adam' (use name) *Telefonkan 'Adam' (guna nama)*
	Dial '0123456789' (use phone number) *Dail '0123456789' (guna nombor telefon)*
System *Sistem*	Turn on Wi-Fi *Hidupkan Wi-Fi*
	Make the screen brighter *Cerahkan skrin*
	Close Weather application *Tutup aplikasi cuaca*
	Open 360 Camera *Buka kamera 360*
Window Control *Kawalan Tingkap*	*Open all windows* *Buka semua tingkap*
	Close sunroof *Tutup tingkap bumbung*
	I want to see the stars *Saya mahu melihat bintang*
Inquiry *Pertanyaan*	What's date today? *Berapa tarikh hari ini?*
	What's time now? *Pukul berapa sekarang?*
Air Control	Turn on AC *Hidupkan AC / aircond*
	Increase the temperature *Naikkan suhu*
	I am cold *Saya sejuk*
	Lower fan speed *Turunkan kelajuan kipas*

Offline Multimedia Unit*

Certain features of the multimedia unit require an internet connectivity, regardless of location or conditions. The offline multimedia unit refers to the multimedia functions that are available when there is no internet connection.

Functions of Multimedia Unit Without Internet Connectivity

Features that is available for the offline multimedia unit are as following :

CATEGORY	FUNCTION	INTERNET CONNECTIVITY	
		WITH	WITHOUT
Basic Functions	1. FM/AM Radio	✓	✓
	2. Bluetooth Connectivity	✓	✓
	3. USB Storage (Music, Photo & Video)	✓	✓
Multimedia Unit Applications	1. Online Music Streaming	✓	X
	2. Navigation	✓	X
	3. Weather	✓	X
	4. Setting (Vehicle Setting)	✓	✓
	5. A-Store	✓	X
	6. VR command (offline features e.g: phone, radio, setting, A/C, vehicle and information)	✓	✓
	7. VR command (online features e.g: online music, navigation, weather, member centre)	✓	X
PROTON Link	1. Vehicle Control	✓	X
	2. Vehicle Status	✓	X
System Upgrade	OTA software version update ***Note:*** without internet connectivity, the system upgrade need to be done via authorised PROTON service outlet.	✓	X

Legend : ✓ Available X Not Available

Voice Recognition (VR) Command for Multimedia Unit Without Internet Connectivity

The following local commands are available for offline multimedia unit:

CATEGORY	FUNCTION	VR COMMAND (EXAMPLE)	WITHOUT INTERNET
Vehicle Control	Window	Windows up / down	✓
	Sunroof*	Sunroof open / close	✓
	Air Conditioning (A/C)	I'm hot / cold	✓
		Set temperature to 24°C	✓
Navigation	Point of Interest (POI) Search	Bring me home / office (location preset)	X
		Bring me to KLCC (specific location)	X
		I'm hungry (restaurant)	X
	Control	Open road condition	X
	Query	My current location	X
Media	Radio	Turn on / off radio	✓
		Volume up / down	✓
		Next / previous station	✓
	Music	Play Maroon 5 (search specific song / singer online)	X
		Play Sugar (search specific song from USB or bluetooth device)	✓
		Volume up / down	✓
		Next / previous song	✓

CATEGORY	FUNCTION	VR COMMAND (EXAMPLE)	WITHOUT INTERNET
Phone	Make phone call	Telephone Adam (specific name from list)	✓
	Emergency call	Call fire station	✓
	Contact history	Open recent call	✓
Others	Weather	What is the weather today?	X
	Calendar	What date is today?	✓
	Quick Command	Home page	✓
		Open map (offline map only)	✓

Legend : ✓ Available X Not Available

Air Conditioner (A/C) System

The air conditioner setting can be customized based on user preferrences via A/C Control Panel in multimedia unit display screen, A/C mini widget in homepage interface and through voice command (refer to VR manual section) for the example of voice command that can be used for A/C system.

A/C Control Buttons

On homepage or any interfaces, swipe up from the A/C area on the dock bar (at the bottom side of multimedia unit display screen) to pull up the A/C control panel interface in full screen.

A/C Control Panel Interface - Full Screen Mode





A/C Control Panel Interface - Small Pop Up Mode

Tap from the fan speed icon of dock bar to get the A/C quick bar. User able to quick adjust fan speed with the arrow.

The small A/C pop-up appears when the physical hardkey is pressed, showing in the second image is the Auto mode.

To adjust the temperature, tap on the temperature arrow or the temperature number.


You can say "Hi Proton, play radio"
14:29
32°C
Few C
Suban
Authorization expired, please
Shah Alam
3
A/C
AUTO
A/C MAX
29.5 °C
4
29.5 °C


You can say "Hi Proton, navigate to KLCC"
14:29
32°C
Few Clouds
Subang Jaya
34°/25°
Authorization expired, please re-login
Login
Shah Alam
AUTO
Phone Link
29.5 °C
4
29.5 °C


You can say "Hi Proton, navigate home"
14:30
32°C
Few Clouds
Subang Jaya
34°/25°
Authorization expired, please re-login
Login
Shah Alam
18
18.5
19
Phone Link
29.5 °C
4
29.5 °C

Description of A/C Buttons

No.	A/C Control System Buttons	Description
1.	Front windshield defrosting/ defogging button	Activate to quickly remove fog or frost on the front windshield
2.	Rear windshield defrosting/ defogging button	Activate to quickly remove fog or frost on the rear windshield
3.	Internal/external air circulation switch button	Switch between external circulation (fresh air) and internal circulation (recirculation) of the air inside the vehicle
4.	A/C button	Turn on the air-conditioning cooling system (A/C compressor)
5.	Air blower adjustment button	Manually adjust the blower fan speed from 0 (min) to 7 (max)
6.	Air vent mode button	Switch the air blowing directions in the air vent or air outlet between windshield blowing mode, face blowing mode, foot blowing mode or any combination of them
7.	A/C MAX button	Activate this button and the air conditioning system operates in the maximum cooling mode.
8.	AUTO button	Activate auto mode and the A/C blower air volume, air outlet mode, and air intake mode will automatically adjust to a state suitable for human comfort based on current temperature
9.	Front passenger seat ventilation button	Tap here to open the seat ventilation speed selection interface and select the desired ventilation speed level between 1, 2 or 3 for left front seat.

No.	A/C Control System Buttons	Description
11.	Front passenger side temperature button	Shows temperature for left zone (front passenger area). Tap here to open the A/C control panel interface.
12.	A/C Interface button	Tap here to open the A/C control panel interface.
13.	Driver side temperature button	Shows temperature for right zone (driver area). Tap here to open the A/C control panel interface.
14.	Driver seat ventilation button	Tap here to open the seat ventilation speed selection interface and select the desired ventilation speed level between 1, 2 or 3 for right front seat.
15.	OFF button	Turn off the air conditioning system.
16.	Temperature adjustment sliding bar at front passenger side	Slide the bar up or down to increase or reduce the temperature at the front passenger side (front left area).
17.	Temperature adjustment sliding bar at driver side	Slide the bar up or down to increase or reduce the temperature at the driver side (front right area).
18.	ION button	Tap to control functions of air purifier (ionizer) by switching in cycle between the silent mode, AUTO mode, and OFF mode for each tap.
19	A/C setting button*	Click this button to open the A/C setting interface*.

Refer to Owner's Manual of this model for more details on the air conditioning system including the A/C buttons, operations and settings.


Vehicle Setting

Tap to open **Vehicle Setting app**  at homepage or from app list interface to enable/ disable, set, and change settings within ten categories : Control Centre, Vehicle Control, Driving, Lighting, ADAS, VR, Appearance, Sound, Connectivity and My Vehicle setting.

Refer to owner's manual of this model for more details of the functions and operations.


Control Centre

The control centre interface act as shortcuts to ease user in finding certain settings. Here, user can set the wireless charging, ambient light, vehicle sound and monitor trip computer. Some other functions can be customised based on user preferences (if fitted).



Vehicle Control

The vehicle control interface are for user to enable or disable the setting related to auto lock and unlock for doors and windows.




In this interface, user will be able to customize by turning on or off the following functions (including but not limited to):

1. **Auto Close Windows after Locking** – When this function is enabled, the windows will close automatically when the vehicle's doors are locked via the intelligent key.
2. **Ignition OFF Auto Unlock** – When this function is enabled, all doors will unlock automatically when the ignition switch is turned to off position (engine off).
3. **Nearby Auto Unlock** – When this function is enabled, all doors will unlock automatically when the intelligent key is within the vehicle detection range. For example when the user is approaching vehicle with the intelligent key.
4. **Walk Away Auto Lock** – When this function is enabled, all doors will be locked automatically when the intelligent key is out of the vehicle detection range. For example when the user walks away from vehicle with the intelligent key.
5. **Auto Close Windows when Raining** – When this function is enabled, the windows will close automatically when the rain sensor detects the rain drops. However, this function has risk of locking the intelligent keys in the vehicle.
6. **Auto Speed Lock*** – This function will automatically lock all doors when driver has started driving the vehicle. The setting can be selected between ***Disable*** (to turn off this function), ***10km/h*** and ***20km/h*** (auto lock will happen at the selected speed).
7. **Lock Notification*** – The type of notification when all doors are locked can be selected between ***Lights Only*** (only turn signal lamp will flash) or ***Horn and Lights***.

Driving

The driving interface allows user to change Driving Mode and driving related features including Drive Mode Linkage (for steering linkage function), Hill Descent Control (HDC), ESC SPORT and AUTO HOLD.




Lighting

In this Lighting interface, user can turn on/off the Headlamp function such as position lamp, fog lamp and headlamp auto function.

User can select to customize the Follow Me Home lamp intervals (time it will stay on). The selection can be between 30s, 60s and 90s.


Select to turn on/off the interior ambient light, with selection of multi-coluor, breathing (tempo) colour and single-color which the colour can be selected at the left interface.



ADAS*


Enter the ADAS interface for function setting where user can customize the setting for various safety related features, such as ACC, ICC, AEB, LKA, RSRS and Intelligent Reminders.


Details of the system functions in ADAS are described in the Owner's Manual.




Under Safety Settings section, each ADAS setting will go to specific pop up interfaces

as shown in the following figures.








VR


See VR setting under Voice Recognition section

Appearance

In the appearance (display) interface, select the background mode between Auto, Day and Night mode. The multimedia unit display screen brightness and meter (including button) brightness can also be adjusted in this interface.



The system language has selection of English and Malay language. The language setting will be reflected on both multimedia unit and meter instrument display.




Sound

Spatial Sound setting in Sound interface is also available at the Control Centre interface. Volume can be adjusted for media, navigation, bluetooth call,system,ringtone, safety tone, alert and notifications. The speed sensitivity volume setting is also available.


Connectivity

In connectivity interface, select the Wi-Fi, Bluetooth and Personal Hotspot setting for internet connection to the multimedia unit.


Wi-Fi : Turn on Wi-Fi, select a network and enter the password to connect.



Bluetooth : Turn on Bluetooth and connect to phone to enable Apple CarPlay or Android Auto connection.




Personal Hotspot : To enable hotspot, view and reset hotspot name and password under connectivity to share network.



My Vehicle

In this interface, the vehicle information and setting are including but not limited to:




Software Update : Check if software updates for multimedia unit is available and to download or install update if required.

Keep the engine on during software update. Power failure may cause the system update to fail. If the system cannot start normally, please contact authorised PROTON service outlet for inspection. ◀


Vehicle Name : Set vehicle's name or license plate number, and to view the vehicle's VIN number.

Trip Computer : View this vehicle trip information either single trip or total trip. Trip information includes Trip Distance, Estimated Trip Duration (EDT), Average Vehicle Speed (EVS) and Average Fuel Consumption (AFC). The single or current trip information


value can be reset either after each refuel or after parking the vehicle (engine off).



Vehicle Maintenance : View this vehicle health status along with the remaining days or mileage until the next maintenance service and setting the wiper service mode.




Storage : View space used by system, apps, media, and remaining available space.



The storage status are inclusive of five sections:

- System – Display the amount of storage space used by system.
- Applications – Display the amount of storage space used by the downloaded and installed applications.
- Media (Music and Multimedia) – Display the amount of storage space used by multimedia local data such as in My Download.
- Others – Display the amount of storage space used by VR and Map local data.
- Remaining – Display the remaining storage space available.

About IHU : Shows hardware, software version, and other details of multimedia unit.



Reset Factory Setting : Reset the IHU (multimedia unit) status to its factory status.


Be cautious when applying this as all user settings will be returned to its default settings and all user data will be deleted. ◀

360 HD Camera*

The 360 HD camera system (or 360 camera) with 180 degree transparent view function assist driver when parking by allowing the driver to monitor real time video images of the front, rear, left, and right sides of the vehicle by displaying footage from the cameras on the multimedia display screen.

360 Camera Interface

The driver can click the specific icon on the 360 camera interface to show different view of images as desired.



1. Settings
   The functions, such as 3D surrounding view, vehicle transparency, radar activation panorama (360 camera view), steering linkage, and obstacle detection trigger function, can be set.
2. Close
   Exit (turn off) the 360 Camera Interface.
3. 2D / 3D view effect
   Switch between the 2D view and the 3D view effects
4. Sensor alarm sound
   The sensor alarm sound can be turned on or off.

Entering the 360 Camera Interface

The 360 Camera interface can be turned on (enter) as follows:

- Tap the **360 Panorama app**  at the multimedia display apps list interface.
- Place the gear in R position to automatically enter the 360 camera interface.
- When the steering linkage function is enabled and the vehicle speed is 30 km/h or below, activating the turn signal lamp will automatically switch the multimedia display to the corresponding left or right 3D view.
- Give a voice command of “HI PROTON, Open 360 Camera” to the multimedia unit.

Exiting the 360 Camera Interface

The 360 Camera interface can be turned off (exit) as follows:

- Tap the **Close button** at the 360 camera interface.
- When the gear is not at R position, the 360 camera interface will exit once the vehicle speed exceeds 15 km/h.
- If the 360 camera interface is entered via the turn signal lamp, the 360 camera interface will automatically exit when the turn signal lamp is turned off.
- Give a voice command of “HI PROTON, Close 360 Camera” to the multimedia unit.
- Shift the gear to Park (P) position. If there is no operation within 5 seconds, 360 Camera will turn off.

PROTON Link Mobile App

Download The App


Available on:

- **Apple App store** – iOS mobile phone
- **Google Play Store** – Android mobile phone
- **AppGallery** – Huawei mobile phone

Steps to Install:

1. Search "**PROTON Link**" in your app store.
2. Tap **Download** and install the app.
3. **Allow all required permissions** when prompted.

Register & Link Your Vehicle




Registration:

- Use the same mobile phone number provided during your vehicle purchase.
- This allows the app to automatically link your vehicle.

Login:

- Enter your **registered phone number** and password.
- Tap "**Forgot Password**" to reset if needed.

If multiple PROTON vehicles are registered under the same account, the earliest purchased vehicle will be set as the default vehicle in the Proton Link App. ◀





Once your account is created, the PROTON Link service will be activated. If you own multiple PROTON vehicles, you may **switch between vehicles** by selecting your preferred model within the app. ◀


Discover


Recommended & Community:

- Stay updated with PROTON's official news that provide corporate announcements.
- Community engagement











Post your moments:

- Tap **[+] / Share Your Moments** to post and share your experiences anytime, anywhere with your friends.







Scan Login:

- Tap **[+] / Share Your Moments** to scan login QR code displayed on the Infotainment Head Unit (IHU) to complete login.

Events:


- In this section, you can **view and participate** in officially organized events. You may **register before the event begins, share the event with friends, and submit your feedback** after the event concludes.





Info:

- Browse to catch up on PROTON latest Models, PROTON Happenings, About PROTON and Motorsports.



Mall

Data Add On via PROTON Link app


- Select your preferred internet data add-on package and follow the on-screen instructions.




Vehicle

Remote Control

- Remote control features include engine start/stop, air conditioning settings, door locks, windows, sunroof, trunk unlock and vehicle locator (horn & lights).
- If PIN code protection is enabled, a 4-digit PIN must be entered to access engine-related functions.





Remote Control Overview



1. **Vehicle Details:** Tap to open the vehicle details page. You can update the vehicle colour or edit the car registration number.
2. **Parking Brake Status:** Displays the status of the parking brake is engaged.
3. **Warning Indicators:** Alerts for any unsual vehicle conditions.
4. **Weather & Fuel Info:** Shows weather forecast, estimated driving range, and remaining fuel.
5. **Vehicle Model Display:** Real-time status oof engine, door locks, and window positions.
6. **Remote Control Functions:** Includes Horn & Lights, Window Open/Close, Door Lock/Unlock, Trunk Open and Engine On/Off.
7. **Air Conditioning Control (A/C):** Turn the A/C On or Off, and set the timer and temperature.
8. **Trip Log:** View your recent travel history.
9. **Vehicle services:** Access related services linked.

Remote Control Icons Descriptions

Tap this icon to access the remote-control page.

Press and hold this icon to lock all doors.

Press and hold this icon to unlock all doors.

Press and hold this icon to activate the horn and lights.

Press and hold this icon to unlock the tailgate*. If the tailgate is not opened within 30 seconds. It will be locked again.

Press and hold this icon to open or partially open the windows.

Press and hold this icon to close all windows.

Press and hold this icon to activate window ventilation.

Press and hold this icon to start the engine remotely. .


Press and hold this icon to turn the A/C on or off.


For some models that this equipped with the power assisted tailgate function, the unlock tailgate function via PROTON link remote control may not be applicable due to safety purpose. ◀

1. You are required to activate a 4-digit PIN code. The PIN is required to use the remote control functions.
2. Operation time may vary depending on mobile network coverage and security verification purposes.
3. The vehicle mobile network coverage availability will depend on your local telecommunication provider.
4. Some functions may be limited or unavailable when the vehicle is outside your local network coverage.
5. Remote control functions are only available when the vehicle is within your local network coverage area.
6. For safety reason, it is recommended to stay near the vehicle during remote operations to prevent unauthorized access. ◀

Air Conditioning Control

At the Air Conditioning Control, you can set the A/C temperature, running time and turn on/off the A/C.







1. **Set Temperature:** Adjust the desired cabin temperature.
2. **Remaning Running Time:** Shows how long the A/C will continue running.
3. **A/C Status:** Indicates weather the A/C is On or Off (Green = A/C On).

Trip Log

1. Tap “**Trip Log**” to view your recent driving history.




2. Press “Time selection” to filter the trip log by a specific time range.



Car Condition


Tap **“Vehicle”→“Car Condition”** to enter the vehicle condition information page.



1. **Vehicle Location:** Display your car’s current position.
2. **Remaining range:** Estimated driving range based on current fuel level.
3. **Driving Stats:** Shows average fuel consumption, total mileage, average speed.
4. **Fuel level:** Indicates the remaining fuel.
5. **Data Usage:** Displays mobile data usage; Tap to visit the mall and purchase a data package.

Map Services


Tap **"Vehicle"→"Map Services"** to open the map page. You can locate your vehicle, send a destination to your car, share your location to invite friends for pickup.




1. **Real-Time Traffic Switch:** Toggle real-time traffic on or off.
2. **Send Location to Car:** Search and select a Point of Interest (POI) before sending it.
3. **Geo-fence:** Access geo-fence setting to set virtual boundaries.
4. **Pick-up invitation:** Send an invite to friends. Once accepted, their location will be shared with you.
5. **Your current location:** Base on your Mobile phone's location.
6. **Vehicle location:** Pinpoint your vehicle's current location.
7. **Search bar:** Enter keywords to find location of interest.
8. **POI type icons:** Includes petrol stations, hotels, and your saved favourites. Favourites are synced with your IHU (multimedia unit).

Geo-Fence

Tap **"Vehicle"→"Map Services"→"Geo-Fence"** icon to open the Geo-Fence page. View your existing geo-fence list or add a new one. Tap an existing item to edit or delete it. When the vehicle exits or enters the set range and the geo-fence is active a notification will be sent to your mobile phone.






1. **Add new Geo-fence:** Set the name of area, area center, area radius and active start time and end time.
2. **Enable / Disable Geo-fence switch:** Turn the geo-fence on or off when the geo-fence time expires, it will automatically pause. You can edit or delete it afterward.

Send Location

Search and select a location to add to your favourites, send it to your car, start navigation to the destination, view the best route and estimated travel time.




1. **Send to Car:** Send your current location to the vehicle car.
2. **Favourite:** Add or remove the location from your favourites.
3. **Share:** Share the current location to a third party platform.
4. **Call:** Dial the phone number that is associated with the location (if available).
5. **Navigate:** Start navigation to the location, and choose a detailed route if needed.


Pick Up A Friend

Tap **“Vehicle”→“Pick Up”** icon to open the invitation page.

- Send a pick-up invitation to your friend.




- If your friend accepts and shares their location, you’ll receive it in the app under **“Profile”→“Message” →“Notifications”.**




Service Appointment

Link to the **Proton Official Website** (https://www.proton.com/en/after-sales/service-appointment), where you can enter your vehicle model to view related services and schedule an appointment.




User Manual

Proton owners to view digital version of their vehicle’s owner’s manuals. You can select your vehicle model to access relevant manuals and guides.




Online Booking

Link to the **Proton Official Website** (https://www.proton.com/en/login), where you can make an online booking. To proceed, you must first register as a Proton member.




Test Drive Booking

Link to the **Proton Official Website** (https://www.proton.com/en/purchase/test-drive-new), where you can **book a test drive** for any Proton vehicle. You can choose your **preferred model, dealer location, and appointment time.**



Loan Calculator



Link to the **Proton Official Website** (https://www.proton.com/en/purchase/loan-calculator), where you can **estimate monthly loan repayments** for Proton


vehicles. You can input the followings to have a quick view of financing options before making a purchase decisions.

- Vehicle price
- Down payment
- Loan tenure
- Interest rate

ProCare Services

Link to the **Proton Official Website** (https://www.proton.com/en/after-sales/procare), where you can get details about **Proton's extended service and protection plans,** including:


- Extended warranty
- Service packages
- Maintenance benefits
- Peace-of-mind ownership support.



Insurance


Link to the **Proton Official Website** (https://www.proton.com/en/purchase/pip-proton-insurance-programme), where you can get information about **insurance packages tailored for Proton owners**, including:

- Comprehensive motor insurance
- Fast claims approval
- Zero excess for own damage claims
- 24/7 roadside assistance
- Panel workshops nationwide
- Proton Insurance Program Enrollment



Dealer


Proton's Dealer Locator helps you find and select your preferred dealer based on **Sales, Service, or Body & Paint** categories. You can view dealer details such as **address, contact number, and send the location directly to your vehicle's IHU (multimedia unit) navigation.**



Profile (My Account)

Profile Overview

Your profile homepage stores all your personal information and related content. You can also edit your details in this section.



1. **System Settings:** Manage account security, notifications, and other preferences.
2. **Message:** View all message types, including likes, comments, mentions, vehicle reports, purchases, and notifications.
3. **Profile Info:** Tap your profile photo or nickname to access your profile homepage.


4. **Posts:** Shows your total post count; tap to view your full post list.

5. **Following:** Users you are currently following.

6. **Followers:** Users who are currently following you.


System Settings

Tap on **“Profile”** → **“Settings”** icon, enter the system settings page. You can change the account security password, remote control PIN code, trip log settings, notification settings, and send feedback to Proton customer service.




Message

View all message types, including likes, comments, mentions, vehicle reports, purchases, and notifications.



Profile Info


Tap your profile photo or nickname to access your profile homepage. It displays all your posted moments and generated photo albums.




My Schedule

Manage your schedule through the PROTON Link App. Once you tap “Allow” to sync, your calendar will sync with the system and send reminder notifications.


- Any new or edited event in the app will automatically sync to the vehicle’s IHU (multimedia unit).
- Make sure to tap “**Save**” after creating or updating a schedule.






Help Center

This section contains all Frequently Asked Questions (FAQs) for the PROTON Link App. You can search for specific questions or browse topics that are relevant to you. Enter Path: **“Profile”** → **“Help Center”**.



Invite Friends


Tap **“Profile”** → **“Invite Friends”** to send your invitation link to your friend. Once the recipient clicks the invitation link, your friend can download the PROTON Link app.



Widget (Vehicle Control)

Widget Overview

The Vehicle Control Widget on your phone’s home screen provides quick access to core vehicle status and controls without opening the full app.



1. **Vehicle Details:** Your car registration number after edit the colour and registration number.
2. **Status:** Last updated status.
3. **Range (km):** Shows the estimated remaining driving range.
4. **Remaining Fuel (L):** Indicates the current fuel level.
5. **Vehicle Model Display:** Display your vehicle model.
6. **Quick Remote Control Functions:** Includes Lock/Unlock Doors, Climate Control, Start/Stop Engine, Horn & Lights.

1. You are required to activate a 4-digit PIN code. The PIN is required to use the remote control functions.

2. Operation time may vary depending on mobile network coverage and security verification purposes.
3. The vehicle mobile network coverage availability will depend on your local telecommunication provider.
4. Some functions may be limited or unavailable when the vehicle is outside your local network coverage.
5. Remote control functions are only available when the vehicle is within your local network coverage area.
6. For safety reason, it is recommended to stay near the vehicle during remote operations to prevent unauthorized access. ◀

How to Add Widget to Home Screen

iPhone :

1. On the home screen, long-press any blank area until apps jiggle.
2. Tap the **"+/edit"** icon at the top-left corner.
3. Scroll or search for **"Proton Link 2.0"** in the widget gallery.
4. Select the **Vehicle Contro**l widget layout and tap **Add Widget.**
5. Drag it to your preferred spot, then tap **"Done"** (top-right).

Android :

1. Long-press an empty area on the home screen.
2. Tap **Widgets** (or the **"Widgets"** icon).
3. Scroll through the widget list until you find **Proton Link 2.0**.
4. Long-press the **"Vehicle Control"** widget, then drag it to your home screen.
5. Release to drop it into your preferred spot.

Huawei :

1. Pinch two fingers together or long-press an empty home-screen area.
2. Tap **"Widgets"** form the menu that appears.
3. Find and tap **"Proton Link 2.0"** in the widget list.
4. Press and hold the **"Vehicle Control"** widget, then drag it onto the home screen.
5. Adjust its size if needed, then tap any blank space to exit arrangement mode.

SCAN QR CODE FOR MORE INFORMATION

PERUSAHAAN OTOMOBIL NASIONAL SDN. BHD. (100995-U)
HICOM Industrial Estate, Batu 3,
P.O Box 7100, 40918 Shah Alam,
Selangor Darul Ehsan, Malaysia.
Fax: +603 5191 1252

Language : ENGLISH
Market : MHR & GEX
Model : X50
Published : JULY 2025
Published in : MALAYSIA

proton.com **PROTON Customer Care 1 800 888 398**

A Member of DRB-HICOM